

OUTDOOR ROPE CARE & MAINTENANCE



Material Properties

Polyester blended ropes are stronger and more abrasion resistant than nylon rope. Unlike nylon rope, polyester has a low stretch factor. This is the exact reason why polyester is a popular choice for boating, marine, and outdoor furniture applications.

The woven character adds aesthetic value, the number of looks are endless. The thickness of the strands, color, texture, patterns are all considered for each design. It has a versatile character that can be mixed and matched with aluminum, steel, and teak frames. Such an interesting material.

One of the best ways to keep outdoor rope looking good and to delay deep or vigorous cleaning is to properly maintain by brushing off any dirt before it becomes embedded, wiping up spills as soon as they occur and spot cleaning soon after stains occur. Particular care should be taken when cleaning the rope, as it forms an integral part of the back panel. Just light brushing & cleaning only.

Outdoor Performance

It is strictly advised not to pull hard on the material as it can be stretched out of shape.

Light Cleaning

1. Lightly brush off any loose dirt
2. Prepare a cleaning solution of 1:16 mild detergent to lukewarm water (less than 100°C/40°C)
3. Apply a generous amount of the cleaning solution to the rope
4. Allow the cleaning solution to soak in and then gently clean with a sponge or soft bristle brush
5. Rinse thoroughly to remove all soap residue and allow to air dry

OUTDOOR ROPE CARE & MAINTENANCE

Stubborn Stains & Mildew

Although the materials used in outdoor rope do not promote mildew growth, mildew may grow on dirt and other foreign substances that are not removed from the rope.

1. Prepare a solution of 4 teaspoons of household bleach & 1 teaspoon of mild detergent per 235-255ml (1-1/2 cups) of lukewarm water
2. Spray the cleaning solution onto the stained area and allow to soak in for 15 minutes
3. Remove the stain with a sponge, clean towel or soft bristle brush
4. Triple rinse thoroughly to remove all soap and bleach residue and allow to air dry

Any residual bleach left in the rope can cause premature deterioration. Prolonged exposure to diluted bleach and full-strength household bleach are not recommended for cleaning rope. Remove all cushions and protect the area around your furniture when using bleach as this can discolor fabrics. Bleach can have harmful effects on the natural environment around you, so please follow all safety and environmental precautions according to the bleach label.